```
%% extra function code
function [x,y] = normpdf2 (mu, sigma2, level, N)
    x = linspace(mu-level*sqrt(sigma2),
mu+level*sqrt(sigma2),N);
    y = normpdf(x, mu, sqrt(sigma2));
end
%% main code
% clear all;
% clc;
[xhat, meas] = sundar filt()
 응응
acc mean = mean(meas.acc(:, ~any(isnan(meas.acc), 1)), 2)
mag mean =mean(meas.mag(:, ~any(isnan(meas.mag), 1)), 2)
gyr mean =mean(meas.gyr(:, ~any(isnan(meas.gyr), 1)), 2)
acc cov = cov(meas.acc(:, \sim(isnan(meas.acc(1,:))))')
mag cov = cov (meas.mag(:, \sim (isnan(meas.mag(1,:))))')
gyr cov = cov(meas.gyr(:, \sim (isnan(meas.gyr(1,:))))')
%% Task 2-a
[xhat, meas] = filterTemplate()
close all;
figure
subplot(3,1,1)
hold on;
grid on;
plot(meas.t', meas.acc', 'LineWidth', 2)
xlim([0, max(meas.t)])
xlabel('time')
ylabel('acceleration')
title ('Accelerometer')
legend('x','y','z')
subplot(3,1,2)
hold on;
grid on;
plot(meas.t', meas.gyr', 'LineWidth', 1)
```

```
xlim([0, max(meas.t)])
xlabel('time')
ylabel('angular velocity')
title ('Gyroscope')
legend('x','y','z')
subplot(3,1,3)
hold on;
grid on;
plot(meas.t', meas.mag', 'LineWidth', 2)
xlim([0, max(meas.t)])
xlabel('time')
ylabel('magnetic field')
title ('Magnetometer')
legend('x','y','z')
%% Task 2-b
[xhat, meas] = filterTemplate()
close all;
axis name = \{'x', 'y', 'z'\};
accelero = meas.acc(:,~isnan(meas.acc(1,:)))';
mu = mean(accelero)
Ra = cov(accelero)
figure
for i=1:3
    subplot(3,1,i);
    hold on;
    grid on;
    histogram(accelero(:,i), 50, 'Normalization','pdf')
    xlabel([axis name{i}, ' [m/s^2]']);
    [x,y] = normpdf2(mu(i), Ra(i,i), 3, 100);
    plot(x,y,'LineWidth',2);
end
sgtitle('acceleration')
gyro = meas.gyr(:,~isnan(meas.gyr(1,:)))';
mu = mean(qyro)
Rw = cov(qyro)
```

```
figure
for i=1:3
    subplot(3,1,i);
    hold on;
    grid on;
    histogram(gyro(:,i), 'Binwidth', 1.01e-3,
'Normalization', 'pdf')
    xlabel([axis name{i},' [rad/s]']);
    [x,y] = normpdf2(mu(i), Rw(i,i), 3, 100);
    plot(x,y,'LineWidth',2);
end
sgtitle('angular velocity')
magneto = meas.mag(:, \sim isnan(meas.mag(1,:)))';
mu = mean(magneto)
Rm = cov(magneto)
figure
for i=1:3
    subplot(3,1,i);
    hold on;
    grid on;
    histogram (magneto(:,i), 'Binwidth', 1.01e-1,
'Normalization', 'pdf')
    xlabel([axis name{i},' [uT]']);
    [x,y] = normpdf2(mu(i), Rm(i,i), 3, 100);
    plot(x,y,'LineWidth',2);
end
sgtitle('magnetic field')
%% Question 12
close all;
[xhat, meas] = sundar filt()
figure;
sgtitle('Orientation estimation comparison')
subplot(3,1,1)
hold on;
grid on;
plot(xhat.t(:,:,1)',180/pi*([1 0
0]*q2euler(xhat.x(:,:,1)))','LineWidth',1.5)
```

```
plot(xhat.t(:,:,1)',180/pi*([1 0
0]*q2euler(meas.orient(:,:,1)))','LineWidth',1.5)
xlabel('time')
ylabel ('phi')
legend('Own','Google')
subplot(3,1,2)
hold on;
grid on;
plot(xhat.t(:,:,1)',180/pi*([0 1
0]*q2euler(xhat.x(:,:,1)))','LineWidth', 1.5)
plot(xhat.t(:,:,1)',180/pi*([0 1
0]*q2euler(meas.orient(:,:,1)))','LineWidth', 1.5)
xlabel('time')
ylabel('theta')
legend('Own', 'Google')
subplot(3,1,3)
hold on;
grid on;
plot(xhat.t(:,:,1)',180/pi*([0 0
1]*q2euler(xhat.x(:,:,1)))','LineWidth', 1.5)
plot(xhat.t(:,:,1)',180/pi*([0 0
1]*q2euler(meas.orient(:,:,1)))','LineWidth', 1.5)
xlabel ('time')
ylabel ('psi')
legend('Own', 'Google')
%% filter code
function [xhat, meas] = sundar filt(calAcc, calGyr, calMag)
% FILTERTEMPLATE Filter template
% This is a template function for how to collect and filter
data
% sent from a smartphone live. Calibration data for the
% accelerometer, gyroscope and magnetometer assumed
available as
% structs with fields m (mean) and R (variance).
```

```
% The function returns xhat as an array of structs
comprising t
% (timestamp), x (state), and P (state covariance) for each
% timestamp, and meas an array of structs comprising t
(timestamp),
% acc (accelerometer measurements), gyr (gyroscope
measurements),
% mag (magnetometer measurements), and orint (orientation
quaternions
% from the phone). Measurements not availabe are marked
with NaNs.
% As you implement your own orientation estimate, it will
% visualized in a simple illustration. If the orientation
estimate
% is checked in the Sensor Fusion app, it will be displayed
in a
% separate view.
% Note that it is not necessary to provide inputs (calAcc,
calGyr, calMag).
  %% Setup necessary infrastructure
  import('com.liu.sensordata.*'); % Used to receive data.
  %% Filter settings
  t0 = []; % Initial time (initialize on first data
received)
           % Assuming that you use q as state variable.
  nx = 4;
  % Add your filter settings here.
q0 = [0.0696 - 0.0410 9.8216]';
rangeSkipAcc = 0.2; % accept acc meas. if 80%|g0| < |acc| <
120% | q0 |
rangeSkipMag = 0.1;
mag\ mean = [-87.1983\ 48.6800\ -73.3492];\ %obtained from
smartphone
m0 = [0 99.86 -73.35]'; %from eqn 9
mx=0:
my = 99.86;
mz = -73.35;
```

```
gyr mean =1.0e-03 * [0.0389 0.2201 -0.0710]';
Ra = 1.0e-03 * [0.0723 0.0014 -0.0009]
              0.0014 0.0624 0.0007
-0.0009 0.0007 0.1149];
               0.0014
                         0.0624
Rm = [ 0.1939   0.0101   -0.0088
      0.0101
               0.1984
                        0.0242
     -0.0088 0.0242 0.1963];
-0.0128 -0.0362 0.3160];
L = norm(m0);
alpha = 0.01;
 % Current filter state.
 x = [1; 0; 0; 0];
 P = eye(nx, nx);
  % Saved filter states.
 xhat = struct('t', zeros(1, 0), ...
               'x', zeros(nx, 0),...
               'P', zeros(nx, nx, 0));
 meas = struct('t', zeros(1, 0),...
               'acc', zeros(3, 0),...
               'gyr', zeros(3, 0),...
               'mag', zeros(3, 0),...
               'orient', zeros(4, 0));
  try
    %% Create data link
    server = StreamSensorDataReader(3400);
    % Makes sure to resources are returned.
    sentinel = onCleanup(@() server.stop());
    server.start(); % Start data reception.
    % Used for visualization.
    figure(1);
```

```
subplot(1, 2, 1);
    ownView = OrientationView('Own filter', gca); % Used
for visualization.
    googleView = [];
    counter = 0; % Used to throttle the displayed frame
rate.
    %% Filter loop
    while server.status() % Repeat while data is available
      % Get the next measurement set, assume all
measurements
      % within the next 5 ms are concurrent (suitable for
sampling
      % in 100Hz).
      data = server.getNext(5);
      if isnan(data(1)) % No new data received
        continue;
                        % Skips the rest of the look
      end
      t = data(1)/1000; % Extract current time
      if isempty(t0) % Initialize t0
        t0 = t;
      end
acc = data(1, 2:4)';
if ~any(isnan(acc)) % Acc measurements are available.
    if abs(norm(acc)-norm(g0)) < norm(g0)*rangeSkipAcc</pre>
        [x, P] = mu g(x, P, acc, Ra, g0);
        [x, P] = mu normalizeQ(x, P);
        ownView.setAccDist(0);
    else
        % skip measurement update
        ownView.setAccDist(1);
    end
end
gyr = data(1, 5:7)';
if ~any(isnan(gyr)) % Gyro measurements are available.
    [x, P] = tu qw(x, P, gyr, 0.001, Rw); %where T=sample
time=0.001
    [x, P] = mu normalizeQ(x, P);
else
Rq = eye(4)*0.1;
[x, P] = randwalk(x, P, Rq);
```

```
[x, P] = mu normalizeQ(x, P);
end
mag = data(1, 8:10)';
if ~any(isnan(mag)) % Mag measurements are available.
    L = (1-alpha) *L+alpha*norm(mag);
    if abs(L-norm(mag)) < L*rangeSkipMag</pre>
        [x, P] = mu m(x, P, mag, Rm, m0);
        [x, P] = mu normalizeQ(x, P);
        ownView.setMagDist(0);
    else
        ownView.setMagDist(1);
    end
end
      orientation = data(1, 18:21)'; % Google's
orientation estimate.
      % Visualize result
      if rem(counter, 10) == 0
        setOrientation(ownView, x(1:4));
        title(ownView, 'OWN', 'FontSize', 16);
        if ~any(isnan(orientation))
          if isempty(googleView)
            subplot(1, 2, 2);
            % Used for visualization.
            googleView = OrientationView('Google filter',
qca);
          end
          setOrientation(googleView, orientation);
          title (googleView, 'GOOGLE', 'FontSize', 16);
        end
      end
      counter = counter + 1;
      % Save estimates
      xhat.x(:, end+1) = x;
      xhat.P(:, :, end+1) = P;
      xhat.t(end+1) = t - t0;
      meas.t(end+1) = t - t0;
      meas.acc(:, end+1) = acc;
      meas.gyr(:, end+1) = gyr;
      meas.mag(:, end+1) = mag;
```